LT3510EFE

DESCRIPTION

Demo circuit 1157A is a dual monolithic step-down DC/DC converter featuring LT®3510. The demo circuit is designed for 3.3V and 1.8V outputs from a 4.5V to 24V input. The current capability of each channel is up to 2A. Independent input voltage, feedback, soft-start and power good pins for each channel simplify complex power supply track-ing/sequencing requirements.

Both converters are synchronized to either a common external clock input or a resistor programmable 250kHz to 1.5MHz internal oscillator. At all frequencies, a 180° phase shift between channels is maintained, reducing voltage ripple and component size. Programmable frequency allows for optimization between efficiency and external component size.

Minimum input-to-output voltage ratios are improved by allowing the switch to stay on through

multiple clock cycles, only switching off when the boost capacitor needs recharging, resulting in about 95% maximum duty cycle.

Each output can be independently disabled using its own soft-start pin, or by using the SHDN pin the entire part can be placed in a low quiescent current shutdown mode.

The LT3510 datasheet gives a complete description of the part, operation and application information. The datasheet must be read in conjunction with this quick start guide for demo circuit 1157A.

Design files for this circuit board are available. Call the LTC factory.

∠ , LTC and LT are registered trademarks of Linear Technology Corporation.

rasio in Ponomiano Gammary (1A-20 0)		
PARAMETER	CONDITION	VALUE
Minimum Input Voltage		4.5V
Maximum Input Voltage		24V
Output Voltage V _{out1}		3.3V ±4%
Output Voltage V _{out2}		1.8V ±4%
Switching Frequency		500kHz ±20%
Maximum Output Current lout1 and lout2		2.0A
Voltage Ripple V _{out1}	V _{IN} =12V, lout1=2A	10mV
Voltage Ripple V _{outz}	V _{IN} =12V, lout2=2A	10mV

Table 1. Performance Summary ($T_A = 25^{\circ}C$)

QUICK START PROCEDURE

Demo circuit 1157A is easy to set up to evaluate the performance of the LT3510. Refer to Figure 1 for proper measurement equipment setup and follow the procedure below:



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1157A DUAL MONOLITHIC STEP-DOWN DC/DC CONVERTER

NOTE: When measuring the input or output voltage ripple, care must be taken to avoid a long ground lead on the oscilloscope probe. Measure the input or output voltage ripple by touching the probe tip directly across the V_{IN} or V_{OUT} and GND terminals. See Figure 2 for proper scope probe technique.

- 1. Place JP1 on the COMBINED position.
- 2. With power off, connect the input power supply to V_{IN1} and GND. (Connect another input power supply to V_{IN2} and GND if INDEPENDENT is selected.)

3. Turn on the power at the input.

NOTE: Make sure that the input voltage does not exceed 24V.

4. Check for the proper output voltages.

NOTE: If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

5. Once the proper output voltage is established, adjust the load within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters.

ADDITIONAL NOTES

1. Install a 10k resistor at R22 if the board is synchronized from an external signal generator. 2. Different tracking and sequencing schemes can be exercised. However, the Vout1 should stay on for proper operation of Vout2.



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1157A DUAL MONOLITHIC STEP-DOWN DC/DC CONVERTER



Figure 1. Proper Measurement Equipment Setup



Figure 2. Measuring Input or Output Ripple



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 1157A DUAL MONOLITHIC STEP-DOWN DC/DC CONVERTER

