

MT29F64G08CBAAAWP-ITZ

[Login or Register to](#)
[Global](#) [Products & Support](#) [NAND Flash](#) [MLC NAND](#) [MT29F64G08CBAAAWP-ITZ](#)
[Add](#) [Email](#)
[See all MLC NAND parts](#) | [See all 64Gb MLC NAND parts](#)

Data Sheets (1)

Data Sheet

[» Download](#)

[Add](#) [Email](#)

Orderable Parts (1)

[» Compare all](#)

Orderable Part Information

Status	Contact Factory	Alternative Part	view
FBGA Code	N/A	SPD Data	N/A
MBQual Data	N/A	Shipping Media	N/A
PLP	No	Start Date	N/A

Specs

Density	64Gb	Status	Contact Factory
RoHS	Yes	Width	x8
Voltage	3.3V	Package	TSOP
Pin Count	48-pin	MT/s	
I/O	Common	Product Name	

Where to Buy

[View All Distributors](#)

Showing 34 Micron Distributors:

« »

Need Help? Contact a sales rep to request samples, get a quote, and receive a callback.

[» Login](#)
[» Find my Rep](#)

Overview

Documentation & Support

Sim Models & Software

FAQs

Recently Added

Date	What was added
01/2014	Datasheet: NAND 64/128/256/512Gb, MLC, Async/Sync, L74A
02/2011	HSpice: NAND 64/128/256/512Gb MLC (Rev A) L74A

FAQs

- » Do you support small block devices?
- » How much ECC do I need to support your devices?
- » I am using the correct amount of error correction code (ECC) for the NAND device, but I'm still seeing bit/byte errors in data I read back from the NAND device.
- » [See all FAQs](#)

Sim Models & Software

Title & Description	Secure	ID	Updated
HSpice: NAND 64/128/256/512Gb MLC (Rev A) L74A Rev. 2.1		L74A	02/2011
IBIS: NAND 64/128/256/512Gb MLC (Rev A) L74A Rev. 2.1		L74A	02/2011

[» See all Sim Models \(2\)](#)

Documentation & Support

Search

 [» Search](#)

Filter

<input type="checkbox"/> Customer Service Note	<input type="checkbox"/> Data Sheet	<input type="checkbox"/> Other Documents
<input type="checkbox"/> Part Numbering Guide	<input type="checkbox"/> Presentation	<input type="checkbox"/> Product Flyer
<input type="checkbox"/> RoHS Certification	<input type="checkbox"/> Technical Note	<input type="checkbox"/> Tool
<input type="checkbox"/> Webinar	<input type="checkbox"/> White Paper	

[+ For MT29F64G08CBAAAWP-ITZ \(3\)](#)
[+ For MLC NAND \(2\)](#)
[+ For NAND Flash \(93\)](#)
[+ For Products and Support \(14\)](#)

Please Note: To view Secure Documents, please [click here](#) or click on a secured document to request access.

Search

 [» Search](#)

Filter

<input type="checkbox"/> NAND Flash Software	<input type="checkbox"/> Sim Model
--	------------------------------------

[+ For MT29F64G08CBAAAWP-ITZ \(2\)](#)
[+ For MLC NAND \(0\)](#)
[+ For NAND Flash \(11\)](#)
[+ For Products and Support \(0\)](#)

Please Note: To view Secure Documents, please [click here](#) or click on a secured document to request access.

Disclaimers

- Micron Models: By downloading any Micron model from this site, you must agree to the terms of [this disclaimer](#) if you do not agree to terms, you do not have permission to use the site or download material from it.
- Non-Micron Models: For your convenience, Micron links to third-party simulation models. Note that Micron does not guarantee functionality or accuracy of these models.

- + Do you support small block devices?
- + How much ECC do I need to support your devices?
- + I am using the correct amount of error correction code (ECC) for the NAND device, but I'm still seeing bit/byte errors in data I read back from the NAND device.

- + How do I achieve greater PROGRAM/READ throughput for the NAND device?
- + How is Nvb specified?
- + I am seeing a lot of READ DISTURB errors. Can you tell me if there is a problem with your part?
- + I've heard that NAND has too many errors to boot from. Is this true?
- + Should I be marking blocks bad due to READ errors?
- + When I issue a Read ID command (99h) to a two-die NAND device, I get a device ID back that states it is a one-die NAND device. Where can I find additional technical information about Micron NAND devices that is not covered in the device data sheets?
- + Where can I find simulation models for NAND Flash devices?
- + Why am I getting a bit/byte error reading back the information I programmed into the NAND device?
- + Why doesn't the NAND Flash device respond correctly to commands issued to it?
- + What is a "bank"?
- + What is the impedance tolerance of the driver in match-impedance mode relative to the expected value base on the perfect reference resistor connected to ZQ pin?
- + Does thermal information change for IT parts?
- + My design was based on a specification stating the JTAG was relative to VDD (1.8V), but now we've discovered that JTAG is actually relative to VDDQ (1.5V). It's a fairly significant board spin to change this: what do I risk by leaving the design as-is? I assume that the specification is still for VDDQ + 0.3V = 1.8V, but with CMOS parts there's no way I can guarantee that it won't swing past that on transitions.
- + Should the ECC memory chip share chip select and CKE signals with the other two main memory chips in our point-to-point application?

+ Who do I contact if I have questions about my buymicron.com order?