

# **KIT33975AEVB Evaluation Board**

Featuring the MC33975A Multiple Switch Detection Interface IC



Figure 1. KIT33975AEVB Evaluation Board

#### Contents

1	Kit Contents/Packing List	. 2
2	Jump Start	. 2
3	Important Notice	. 3
4	Introduction	. 4
5	Evaluation Board Features	. 4
6	MC33975A Device Features	. 4
7	Accessory Interface Board	. 5
8	Required Equipment	. 5
9	Evaluation Board Configuration.	. 6
10	Installing SPIGen Freeware on your Computer.	. 7
11	Setup and Using the Hardware	. 8
12	2 Schematic	. 9
13	Board Layout	10
14	4 Bill of Material   Bill of Material	13
15	5 References	14
16	Revision History	15





### 1 Kit Contents/Packing List

- Assembled and tested evaluation board/module in anti-static bag.
- Warranty card

#### 2 Jump Start

- Go to www.freescale.com/analogtools
- Locate your kit
- Review your Tool Summary Page
- Look for



• Download documents, software, and other information





#### 3 Important Notice

Freescale provides the enclosed product(s) under the following conditions:

This evaluation kit is intended for use of ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY. It is provided as a sample IC pre-soldered to a printed circuit board to make it easier to access inputs, outputs, and supply terminals. This evaluation board may be used with any development system or other source of I/O signals by simply connecting it to the host MCU or computer board via off-the-shelf cables. This evaluation board is not a Reference Design and is not intended to represent a final design recommendation for any particular application. Final device in an application will be heavily dependent on proper printed circuit board layout and heat sinking design as well as attention to supply filtering, transient suppression, and I/O signal quality.

The goods provided may not be complete in terms of required design, marketing, and or manufacturing related protective considerations, including product safety measures typically found in the end product incorporating the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. In order to minimize risks associated with the customers applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards. For any safety concerns, contact Freescale sales and technical support services.

Should this evaluation kit not meet the specifications indicated in the kit, it may be returned within 30 days from the date of delivery and will be replaced by a new kit.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts.

Freescale does not convey any license under its patent rights nor the rights of others. Freescale products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale product could create a situation where personal injury or death may occur.

Should the Buyer purchase or use Freescale products for any such unintended or unauthorized application, the Buyer shall indemnify and hold Freescale and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale was negligent regarding the design or manufacture of the part.Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2014



#### 4 Introduction

The Evaluation Kit features the MC33975A a multiple switch detection interface with suppressed wake-up. The kit is designed to detect the closing and opening of up to 22 switch contacts. The switch status, either open or closed, is transferred to the microprocessor unit (MCU) through a serial peripheral interface (SPI). The device also features a 22-to-1 analog multiplexer for reading inputs as analog.

#### 5 Evaluation Board Features

The board's main features are as follows:

- The MC33975A can monitors as many as 22 switches and provide their states as information to a PC for evaluation.
- An onboard 16-pin USB port connects to the PC through the Freescale SPI-to-USB Interface Dongle (KITUSBSPIDGLEVME). See "Accessory Interface Board".
- The MC33975A device can be programmed using the SPIGen utility running on the PC. See "Installing SPIGen Freeware on your Computer".
- LEDs report the status of the MC33975A Interrupt (INT) and wake-up lines

#### 6 MC33975A Device Features

The MC33975A device supports the following functions:

- Designed to operate from 5.5 V  $\leq$  V<sub>PWR</sub>  $\leq$  28 V
- Switch input voltage range -14 V to VPWR
- Interfaces to microprocessor using 3.3 V/5.0 V SPI protocol
- Selectable wake-up on change of state
- 14 switch-to-ground inputs
- Eight programmable inputs (switches to battery or ground)
- Selectable wetting current (32 mA or 4.0 mA for switch-to-ground inputs)
- Sleep State current: VPWR = 100 μA, VDD = 20 μA

Freescale analog ICs are manufactured using the SMARTMOS process, a combinational BiCMOS manufacturing flow that integrates precision analog, power functions and dense CMOS logic together on a single cost-effective die.



## 7 Accessory Interface Board

The KIT33975AEVB board may be used with the KITUSBSPIDGLEVME interface dongle (shown below), which provides a USB-to-SPI interface. This small board makes use of the USB and SPI ports built into Freescale's MC68HC908JW32 microcontroller. The main function provided by this dongle is to allow Freescale evaluation boards that have an SPI port to communicate with a PC through its USB port.



Figure 2. KITUSBSPIDGLEVME Interface Dongle

#### 8 Required Equipment

Minimum equipment required:

- DC power supply
- USB-enabled PC with Windows XP or higher
- KITUSBSPIDGLEVME Interface Dongle

Downloaded from Arrow.com.



# 9 Evaluation Board Configuration



Figure 3. KIT33975AEVB plus KITUSBSPIDGLEVME Board Setup



#### 10 Installing SPIGen Freeware on your Computer

The latest version of SPIGen is designed to run on any Windows 8, Windows 7, Vista or XP-based operating system. To install the software, go to www.freescale.com/analogtools and select your kit. Click on that link to open the corresponding Tool Summary Page. Look for "Jump Start Your Design". Download the SPIGen software and the associated configuration file to your computer desktop.

Run the install program from the desktop. The Installation Wizard will guide you through the rest of the process.

To use SPIGen, go to the Windows Start menu, then Programs, then SPIGen, and click on the SPIGen icon. The SPIGen Graphic User Interface (GUI) will appear. Go to the file menu in the upper left hand corner of the GUI, and select "Open". In the file selection window that appears, set the "Files of type:" drop-down menu to "SPIGen Files (\*.spi)". (As an exceptional case, the file name may have a .txt extension, in which case you should set the menu to "All Files (\*.\*)".) Next, browse for the configuration file you saved on your desktop earlier and select it. Click "Open", and SPIGen will create a specially configured SPI command generator for your evaluation board.

The GUI is shown in <u>Figure 4</u>. The text at the top is the name of the configuration file loaded. The left side panel displays folders that group user interfaces. The process of loading the configuration file has assigned a list of "Extra Pins" as well as a list "Quick Commands", all of which are board-specific.

🧾 configuration_file_na	ne.spi - SPIGen 📃 🗖 🔀
: 🗋 💕 🖬   🐰 🖻 🛍	
Device View 🛛 🗘 🗙	
	Word To Send
Generic	Length In Bits:    B  Length In Bits:  Length In Bits: Length I
Batch Commands	0
H MC33813 H MC33814	
🕀 🗁 MC33816	Send Once Send
± / / MC33909	Continuously
	SPI Word Session Log Extra Pins Quick Commands
	Data 0 High Low
	Data 1 High Low
	Data 2 High Low
	Data 3 High Low
	Data 4 High Low
	Control 0 High Low
	Control 1 High Llow
	Save Clear Set Defaults Save Delete
Ready	The SPI dongle was not detected. Word Sent: 0x0000000000 Word Rcvd: 0x0000000000 CAPI NUM SCRU

Figure 4. SPIGen GUI

KT33975UG User's Guide Rev. 2.0 2/2014

Freescale Semiconductor, Inc.

7



#### **11** Setup and Using the Hardware

In order to perform the demonstration examples, first set up the evaluation board hardware and software as follows:

- 1. The KIT33975AEVB evaluation card allows the customer to quickly evaluate features of the device with a simple bench top setup. All switch inputs may be evaluated using the onboard switch banks or actual system switches connected to the switch input edge connector.
- 2. Using a standard USB cable, the USB to SPI dongle board and the enclosed SPIGen SPI Driver software, you can use a personal computer to provide the Serial Peripheral Interface (SPI) communication with this EVB. (See Evaluation Board Configuration).
- Connect power supply to the +12 V and GND terminals on the EVB's power terminal block. Make sure the voltages provided are in accordance with the device data sheet and that the supply currents are sufficient to supply the switch contact wetting current.
- 4. With power applied to the KIT33975AEVB evaluation card, the MC33975A device will be in NORMAL mode with both LEDs illuminated. The MC33975A device is now ready to receive SPI commands and be configured via the SPI to read the switch inputs. External switches may be used to evaluate the device.
- 5. To use SPIGen, go to the Windows Start menu, then Programs, then SPIGen, and click on the SPIGen icon. The SPIGen GUI will appear. Loading of the configuration file specific to the KIT33975AEVB board is described in section "Installing SPIGen Freeware on your Computer". Once having loaded the configuration file, SPIGen will open a specifically configured SPI command generator for the evaluation board. The configuration file will set all parameters for SPI signals from the PC and provide a list of commands that may be sent to the EVB.
- 6. To initialize the MC33975A device to read switch inputs, the user may use batch commands. To do this, select the "Batch Commands" option inside the "Generic" folder on the left-hand panel. In the window that appears, select "Full Initialize" from the "Batch Name" drop-down menu. To send this batch of commands to the evaluation board, click the "Send Once" tab.
- 7. To quickly evaluate the board as well as the MC33975A device, simply select the "Single Command" option inside the "Generic" folder on the left-hand panel. In the window that appears, select the "Switch Status" command from the "Quick Commands" list, then click the "Send Continuously" button. The opening and closing of switches may now be seen in the "Word Rcvd" field located at the bottom of the SPIGen GUI. Refer to the MC33975A Data Sheet for detailed information on I/O communication and device operation.



#### **12 Schematic**



Figure 5. Evaluation Board Schematic

KT33975UG User's Guide Rev. 2.0 2/2014



#### 13 **Board Layout**

Assembly Layer Top 13.1





#### 13.2 Top Layer Routing



KT33975UG User's Guide Rev. 2.0 2/2014



#### 13.3 Bottom Layer Routing





#### 14 Bill of Material

Qty	Schematic Label	Value	Description	Package			
Integ	ntegrated Circuits						
1	MC33975ATEK		Multiple Switch Detection Interface	SO-32WB			
Diodes							
1	D1	1.0 amp	Schottky Diode MURS120T3G	SMB			
LEDs	LEDs						
1	WAKEB		Green Through Hole LED	2.5 mm LED			
1	INTB		Red Through Hole LED	2.5 mm LED			
Capacitors							
25	C1-C25	100 nF	50V X7R CAP	C0805			
Resistors							
2	R8, R9	1.0 K	5% Resistor	R0805			
Switches, Connectors, and Board							
1	JP1		1 x 2 Pin Header Straight				
1	SV3,JP1		1 x 3 Pin Header Straight				
1	SV4,JP1		1 x 6 Pin Header Straight				
1	SV6		2 x 8 Pin Header Straight				
1	SV1,SV2, SV5		1 x 22 Pin Header 90 Degree				
1	X1		AK500/2 2-Terminal Power Connector				

Note: Freescale does not assume liability, endorse, or warrant components from external manufacturers that are referenced in circuit drawings or tables. While Freescale offers component recommendations in this configuration, it is the customer's responsibility to validate their application.



### 15 References

Following are URLs where you can obtain information on related Freescale products and application solutions:

Freescale.com Support Pages	URL
MC33975 Product Summary Page	http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=MC33975
KIT33975AEVB Tool Summary Page	http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=KIT33975AEVB
KITUSBSPIDGLEVME Tool Summary Page	http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=KITUSBSPIDGLEVME
SPIGen Tool Summary Page	http://www.freescale.com/files/soft_dev_tools/software/device_drivers/SPIGen.html
Analog Home Page	http://www.freescale.com/analog
Automotive Home Page	http://www.freescale.com/automotive

#### 15.1 Support

Visit www.freescale.com/support for a list of phone numbers within your region.

#### 15.2 Warranty

Visit www.freescale.com/warranty for a list of phone numbers within your region.



## 16 Revision History

Revision	Date	Description of Changes
1.0	7/2013	Initial release
2.0	2/2014	Updated kit name

Freescale Semiconductor, Inc.





#### How to Reach Us:

Home Page: freescale.com

Web Support: freescale.com/support Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. SMARTMOS is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2014 Freescale Semiconductor, Inc.

Document Number: KT33975UG Rev. 2.0 2/2014

