

Dual, 2-Phase Step-Down Switching Controller

DESCRIPTION

Demonstration circuit 927 is a high density 5V/4A and 3.3V/4A step down converter featuring the LT3742. A 500kHz fixed frequency current mode architecture provides fast transient response with simple loop compensation components and cycle-by-cycle current limiting. An internal step-up regulator is used to generate the gate drive voltage, allowing the gate of the external high side N-channel MOSFET to be driven to full enhancement for the highly efficient operation. The dual channels operate 180° out of phase to reduce the input ripple current, minimizing the noise induced on the input supply, and allow-

ing the use of less input capacitance. The device also includes individual shutdown and power-good output for each converter. The LT3742 is available in a small 4mm x 4mm QFN package.

The LT3742 datasheet gives a complete description of the part, operation and application information. The datasheet must be read in conjunction with this quick start guide for demo circuit 927.

Design files for this circuit board are available. Call the LTC factory.

LTC, LTC and LT are registered trademarks of Linear Technology Corporation. ThinSOT and PowerPath are trademarks of Linear Technology Corporation.

Table1. Performance Summary ($T_A = 25^\circ\text{C}$)

PARAMETER	CONDITION	VALUE
Minimum Input Voltage		5.5V
Maximum Input Voltage		28V (Note 1)
Output Voltage $V_{\text{OUT}1}$		5V +/-3%
Output Voltage $V_{\text{OUT}2}$		3.3V +/-3%
Maximum Output Current $I_{\text{OUT}1}$		4A
Maximum Output Current $I_{\text{OUT}2}$		4A
Typical Switching Frequency		500kHz

Note 1: See "Input Voltage Range" section in the datasheet for detail.

QUICK START PROCEDURE

Demonstration circuit 927 is easy to set up to evaluate the performance of the LT3742. Refer to Figure 1 for proper measurement equipment setup and follow the procedure below:

NOTE. When measuring the input or output voltage ripple, care must be taken to avoid a long ground lead on the oscilloscope probe. Measure the input or output voltage ripple by touching the probe tip directly across the Vin or Vout and GND terminals. See Figure 2 for proper scope probe technique.

1. Place JP1 and JP2 on the RUN position:
2. With power off, connect the input power supply to Vin and GND.

3. Turn on the power at the input.

NOTE. Make sure that the input voltage does not exceed the maximum input voltage.

4. Check for the proper output voltages.

NOTE. If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

5. Once the proper output voltages are established, adjust the loads within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters.




Figure 1. Proper Measurement Equipment Setup




Figure 2. Measuring Input or Output Ripple

