General Purpose Transistor NPN Silicon 2N4264 COLLECTOR 3 2 BASE EMITTER MAXIMUM RATINGS CASE 29-04, STYLE 1 Symbol Rating Value Unit TO-92 (TO-226AA) Collector-Emitter Voltage Vdc VCEO 15 30 Vdc Collector-Base Voltage VCBO Vdc Emitter-Base Voltage VEBO 6.0 Collector Current — Continuous IC 200 mAdc

350

2.8

1.0

8.0

-55 to +150

mW

mW/°C

Watts

mW/°C

°C

Operating and Storage Junction Temperature Range

Total Device Dissipation @ $T_A = 25^{\circ}C$

Total Device Dissipation @ $T_C = 25^{\circ}C$

Derate above 25°C

Derate above 25°C

THERMAL CHARACTERISTICS

Characteristic	Symbol	Мах	Unit
Thermal Resistance, Junction to Ambient	$R_{\theta JA}$	357	°C/W
Thermal Resistance, Junction to Case	$R_{\theta}JC$	125	°C/W

 P_{D}

 P_{D}

TJ, Tstg

ELECTRICAL CHARACTERISTICS (T_A = 25°C unless otherwise noted)

Characteristic	Symbol	Min	Max	Unit
OFF CHARACTERISTICS				
Collector-Emitter Breakdown Voltage $(I_C = 1.0 \text{ mAdc}, I_B = 0)$	V _(BR) CEO	15	_	Vdc
Collector-Base Breakdown Voltage $(I_{C} = 10 \ \mu Adc, I_{E} = 0)$	V _(BR) CBO	30	_	Vdc
Emitter-Base Breakdown Voltage $(I_E = 10 \ \mu Adc, I_C = 0)$	V _{(BR)EBO}	6.0	_	Vdc
Base Cutoff Current (V _{CE} = 12 Vdc, V _{EB(off)} = 0.25 Vdc) (V _{CE} = 12 Vdc, V _{EB(off)} = 0.25 Vdc, T _A = 100°C)	IBEV		0.1 10	μAdc
Collector Cutoff Current (V _{CE} = 12 Vdc, V _{EB(off)} = 0.25 Vdc)	ICEX	_	100	nAdc

REV 2

© Motorola, Inc. 1997



2N4264

	Characteristic	Symbol	Min	Max	Unit		
ON CHARACTERISTI	CS	-			-		
DC Current Gain $(I_{C} = 1.0 \text{ mAdc}, V_{CE} =$ $(I_{C} = 10 \text{ mAdc}, V_{CE} =$ $(I_{C} = 10 \text{ mAdc}, V_{CE} =$ $(I_{C} = 30 \text{ mAdc}, V_{CE} =$ $(I_{C} = 100 \text{ mAdc}, V_{CE} =$ $(I_{C} = 200 \text{ mAdc}, V_{CE} =$	1.0 Vdc) 1.0 Vdc, T _A = -55°C) 1.0 Vdc) = 1.0 Vdc) ⁽¹⁾	hFE	25 40 20 40 30 20	— 160 — — — —	_		
Collector-Emitter Satura ($I_C = 10 \text{ mAdc}, I_B = 1.$ ($I_C = 100 \text{ mAdc}, I_B = 1$	V _{CE(sat)}		0.22 0.35	Vdc			
$\begin{array}{l} Base-Emitter Saturation\\ (I_C = 10 \text{ mAdc}, I_B = 1.)\\ (I_C = 100 \text{ mAdc}, I_B = 1.)\end{array}$) mAdc)	V _{BE(sat)}	0.65 0.75	0.8 0.95	Vdc		
SMALL-SIGNAL CHA	RACTERISTICS						
Current-Gain — Bandwi (I _C = 10 mAdc, V _{CE} =		fΤ	300	-	MHz		
Input Capacitance (V _{EB} = 0.5 Vdc, I _C = 0	, f = 1.0 MHz)	C _{ibo}	_	8.0	pF		
Output Capacitance (V _{CB} = 5.0 Vdc, I _E = 0	, f = 1.0 MHz, I _E = 0)	C _{obo}	_	4.0	pF		
SWITCHING CHARAC	TERISTICS			•			
Delay Time	(V _{CC} = 10 Vdc, V _{EB(off)} = 2.0 Vdc,	td	—	8.0	ns		
Rise Time	$I_{C} = 100 \text{ mAdc}, I_{B1} = 10 \text{ mAdc})$ (Fig. 1, Test Condition C)	tr	_	15	ns		
Storage Time	$V_{CC} = 10 \text{ Vdc}, (I_C = 10 \text{ mAdc}, \text{ for } t_S)$	t _s	—	20	ns		
Fall Time	(I _C = 100 mA for t _f) (I _{B1} = −10 mA) (I _{B2} = 10 mA) (Fig. 1, Test Condition C)	t _f	—	15	ns		
Turn–On Time							
Turn–Off Time	$ (V_{CC} = 3.0 \text{ Vdc}, I_C = 10 \text{ mAdc}, \\ I_{B1} = 3.0 \text{ mAdc}, I_{B2} = 1.5 \text{ mAdc}) \text{ (Fig. 1, Test Condition A)} $						
Storage Time	$(V_{CC} = 10 \text{ Vdc}, I_C = 10 \text{ mA},$ $I_{B1} = I_{B2} = 10 \text{ mAdc}) \text{ (Fig. 1, Test Condition B)}$	t _s	_	20	ns		


1. Pulse Test: Pulse Width = $300 \,\mu$ s, Duty Cycle = 2.0%.

Total Control Charge

Test Condition	IC	vcc	Rs	RC	C _{S(max)}	V _{BE(off)}	V ₁	V ₂	V ₃
	mA	V	Ω	Ω	pF	V	V	V	V
A	10	3	3300	270	4	-1.5	10.55	-4.15	10.70
В	10	10	560	960	4	—	—	-4.65	6.55
С	100	10	560	96	12	-2.0	6.35	-4.65	6.55

 $(V_{CC} = 3.0 \text{ Vdc}, I_C = 10 \text{ mAdc}, I_B = \text{mAdc})$ (Fig. 3, Test Condition A)





80

рС

 Q_T

CURRENT GAIN CHARACTERISTICS




Figure 2. Minimum Current Gain




Figure 3. QT Test Circuit




Figure 4. Turn–Off Waveform

When a transistor is held in a conductive state by a base current, I_B, a charge, Q_S , is developed or "stored" in the transistor. Q_S may be written: $Q_S = Q_1 + Q_V + Q_X$.

 ${\sf Q}_1$ is the charge required to develop the required collector current. This charge is primarily a function of alpha cutoff frequency. ${\sf Q}_V$ is the charge required to charge the collector–base feedback capacity. ${\sf Q}_X$ is excess charge resulting from overdrive, i.e., operation in saturation.


The charge required to turn a transistor "on" to the edge of saturation is the sum of Q₁ and Q_V which is defined as the active region charge, Q_A. Q_A = I_{B1}t_f when the transistor is driven by a constant current step


 (I_{B1}) and $I_{B1} < < \frac{I_C}{h_{FE}}$.

NOTE 1

If I_B were suddenly removed, the transistor would continue to conduct until Q_S is removed from the active regions through an external path or through internal recombination. Since the internal recombination time is long compared to the ultimate capability of a transistor, a charge, Q_T, of opposite polarity, equal in magnitude, can be stored on an external capacitor, C, to neutralize the internal charge and considerably reduce the turn–off time of the transistor. Figure 3 shows the test circuit and Figure 4 the turn–off waveform. Given Q_T from Figure 13, the external C for worst–case turn–off in any circuit is: $C = Q_T/\Delta V$, where ΔV is defined in Figure 3.

"ON" CONDITION CHARACTERISTICS








Figure 6. Saturation Voltage Limits



DYNAMIC CHARACTERISTICS




Figure 8. Delay Time




Figure 9. Rise Time





Figure 13. Maximum Charge Data

PACKAGE DIMENSIONS



Motorola reserves the right to make changes without further notice to any products herein. Motorola makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Motorola assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Motorola data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Motorola does not convey any license under its patent rights or the rights of others. Motorola products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Motorola product could create a situation where personal injury or death may occur. Should Buyer purchase or use Motorola products for any such unintended or unauthorized application, Buyer shall indemnify and hold Motorola and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Motorola was producted with such and the part. was negligent regarding the design or manufacture of the part. Motorola and 🛞 are registered trademarks of Motorola, Inc. Motorola, Inc. is an Equal Opportunity/Affirmative Action Employer.

How to reach us:

USA/EUROPE/Locations Not Listed: Motorola Literature Distribution; P.O. Box 5405, Denver, Colorado 80217. 303-675-2140 or 1-800-441-2447 JAPAN: Nippon Motorola Ltd.: SPD, Strategic Planning Office, 4-32-1,

Mfax is a trademark of Motorola. Inc.

Nishi-Gotanda, Shinagawa-ku, Tokyo 141, Japan. 81-3-5487-8488

Mfax™: RMFAX0@email.sps.mot.com - TOUCHTONE 602-244-6609

INTERNET: http://motorola.com/sps



ASIA/PACIFIC: Motorola Semiconductors H.K. Ltd.; 8B Tai Ping Industrial Park, - US & Canada ONLY 1-800-774-1848 51 Ting Kok Road, Tai Po, N.T., Hong Kong. 852-26629298

 \Diamond